# SINCLAIR RESEARCH

#### X1 BUTTON RADIO WITH FM AUTO SCAN

#### THANK YOU FOR PURCHASING THE X1 BUTTON RADIO

#### Instructions for Use (fig 1)

- · Gently unwind aerial wire for best reception.
- Slide the 'ON/OFF' switch to the 'ON' position.
  - · Press the 'RESET' button once.
- Place the X1 Button Radio in either ear, (clip on the optional ear clip for a snugger fit - fig 2).
- Press the 'SCAN' button until you tune in to your desired FM station.
- To reduce the volume withdraw the earpiece slightly from your ear.
- To conserve power, ensure the radio is switched off when not in use.
- The foam earpiece may be removed and washed with a mild detergent.
- When the sound becomes weak or distorted replace the battery (see below)



### Installing/Replacing the Battery (CR2032 Button Cell)

- Gently lift the top clip and pull the printed cover off (fig 3).
- If replacing the battery, slide the old battery out.
- Insert new battery under tab with '+' side facing up (fig 4).
- Line up both clips and snap cover into place (fig 4). (The cover will only fit the correct way around do not force it).



## If the Radio does not Operate

- · Make sure the battery is fresh and properly installed.
  - Gently unwind the aerial fully.
- · Test in an area of known good reception.
- Switch the radio 'OFF' and then 'ON' again.
- · Try a new battery.

#### Specification

- Frequency Range FM Band (88-108 MHz)
- Power Source Lithium Battery (CR2032) 3 volts